WOOD PROTECTION End Grain Sealer 1 LITRE

PREPARATIONS: Apply Wood Protection End Grain Sealer to completely clean wood ends. Cover furniture, objects that are sensitive to splashes, as well as glass, aluminum, stones and tiles – the products are slightly alkaline and can leave stains.

REMEMBER: Avoid rain until all coats have dried. Avoid application in strong sunlight because the treatment will dry too quickly. Lowest temperature for use: +6°C. Shake and stir before and during treatment. Wipe away any spills immediately with a wet rag.

STEP 1 – WOOD PROTECTION END GRAIN SEALER: Apply Wood Protection End Grain Sealer to a dry surface using a broad brush or a roller, allow to dry for at least 2 hours. The ends sucks in the fluid quite a bit, allow to dry, preferably with a hot air gun or other fan. Avoid boiling. Apply another coat of Wood Protection End Grain Sealer, allow to dry for at least 4 hours.

STEP 2 - SURFACE PROTECTION END GRAIN SEALER:

Finish treatment using Surface Protection End Grain Sealer.

WHAT DOES SURFACE PROTECTION END GRAIN SEALER CONTAIN?

Silicon, potassium, natural plant parts and water. The products are tested/ approved according to the standards of EN 84 + EN 113 for use above ground according to EN 335-2.

WHAT DO I DO IF I HAVE QUESTIONS?

Read more at sioox.org.uk or contact your dealer.

Store frost-free. Shelf life in well-filled sealed container is up to 6 years. Sort rinsed packaging as hard plastic.

Reservation for possible changes. For the latest information, see sioox.org.uk.



Sioo Wood Protection AB. www.sioox.org.uk

SURFACE PROTECTION End Grain Sealer

PREPARATIONS: Surface Protection End Grain Sealer should be applied on ends treated with step 1, treated ends. Protect all nearby surfaces from splashes, especially pretreated surfaces. Cover furniture, objects that are sensitive to splashes, as well as glass, aluminum, stones and tiles – the products are slightly alkaline and can leave stains.

APPLICATION ADVICE: Avoid rain. Avoid application in strong sunlight because the treatment will dry too quickly. Lowest temperature for use: +6°C.

STEP 1 – SURFACE PROTECTION END GRAIN SEALER: Treat the surface with Wood Protection End Grain Sealer.

STEP 2 – WOOD PROTECTION END GRAIN SEALER: Shake and stir before and during treatment. Apply Step 2 on the ends. Wipe away any spills immediately with a wet rag. Allow to dry, preferably with a hot air gun or other fan. Avoid boiling. Apply Premium Surface Protection Deck one more time after 4–7 years.

WHAT DOES PREMIUM SURFACE PROTECTOR CONTAIN? Silicone emulsion and water.

WHAT DO I DO IF I HAVE QUESTIONS? Read more at sioox.org.uk or contact your dealer.

Store at temperatures of 5–30 deg °C. Shelf life in well filled sealed containers is up to 2 years. Dispose of used packaging as hard plastic. In case of contact with eyes or skin wash with water.

Reservation for possible changes. For the latest information, see sioox.org.uk.



Sioo Wood Protection AB. www.sioox.org.uk